






## 6.2 INSTALLATION OF MARKER M11.0 TC EPS (UPDATE 11/6/14)



### DRILLING THE ATTACHMENT HOLES:

See ADJUSTMENT OF INSTALLATION TOOLS → 3.2

### INSTALLATION UPDATE 11/6/14

- Make a mark on ski **6mm behind** the Original Mounting Position (A) on the ski. (6.2 - 2) Place the MARKER universal installation tool W001G1T or W012J1T (6.2 - 1) on the mark 6mm behind the Original Mounting Position (B) on the ski. (6.2 - 2)
- Drill 3 holes for the front plate (toe) through the green marked drill bushings.
- Drill 4 holes for the heel plate (heel) through the green marked drill bushings.
- Remove the installation tool from the ski.

### REMARK:

See DRILLING INSTRUCTIONS → 3.2

### INSTALLING THE TOE:

- Place the toe with the pre - installed screws onto the ski.
- Tighten the screws lightly, then firmly (6.2 - 3)

### INSTALLING THE HEEL:

- Place the heel with the pre - installed screws onto the ski.
- Tighten the screws lightly, then firmly (6.2 - 4)

### CHECK FORWARD PRESSURE:

- Place the ski boot into the binding and close it.
- Check if the forward pressure adjustment screw is flush with the back of the heel housing. (6.2 - 5)  
If this adjustment is incorrect, turn the screw until it is flush with the back of the housing.
- Remove the ski boot, then re - insert it into the binding and re-check the adjustment.



### CAUTION !

Make sure that you do not exceed the back stop when adjusting the sole length backward !

### RELEASE VALUE SELECTION AND ADJUSTMENT:

- Following the correct adjustment for sole length and forward pressure, the release value has to be selected and adjusted.

See RELEASE VALUE SELECTION AND ADJUSTMENT:

→ 11.1 - 11.3



**CAUTION !** The release value selection and adjustment has to be done very accurately to care for the skier's safety. All key information including the release value must be recorded in the workshop form. → 14.3